



Ottumwa Amateur Radio Club Remote Connection to Flex 6400 for Windows

Install SmartSDR software


1. Open a web browser and go to the FlexRadio SmartSDR software page.
<https://www.flexradio.com/ssdr/>
2. Scroll down the page to the SDR for Windows section and click on the Download Latest V3 Release button.




3. Select button to download the SmartSDR Installer executable. At the time of this writing the button is labeled **DOWNLOAD 3.2.39 SOFTWARE – 53.78 MB**. It is likely that the software may be a different version number at the time of the download.




4. Follow the install steps
 - a. Select **Yes** for Do you want to allow this app to make changes to your device?
 - b. Choose **I accept the agreement** then select **Next**




- c. On the Select Components dialog box make sure **DAX application files** and **SmartSDR CAT application files** are checked and select **Next**.




- d. On the Select Additional Tasks dialog box make sure that **Create a desktop shortcut** and select **Next**.



- e. On the Ready to Install dialog box select **Install**.



- f. There may be several screens that pop up asking to install drivers. Select Ok to all of the dialog boxes.
- g. On the Complete dialog box, un-check the **View the Release Notes** and **View the changelog** selections and select **Finish**.




Connect to Remote Radio


1. Double Click on the SmartSDR Icon on the desktop.



2. Click on the Log In button.



3. Enter the remote user email address and the remote user password (Supplied separately) and select the Log In button.



4. Click the Connect button to connect to the Flex-6400.

